

IN712MEB***0000 Configuration Guide

700series Metering

Version 1.0.0
Publication date 2025-06-30



Intesis MAPS

Copyright © 2025 Intesis

Disclaimer

The information in this document is for informational purposes only. Please inform HMS Networks of any inaccuracies or omissions found in this document. HMS Networks disclaims any responsibility or liability for any errors that may appear in this document.

HMS Networks reserves the right to modify its products in line with its policy of continuous product development. The information in this document shall therefore not be construed as a commitment on the part of HMS Networks and is subject to change without notice. HMS Networks makes no commitment to update or keep current the information in this document.

The data, examples and illustrations found in this document are included for illustrative purposes and are only intended to help improve understanding of the functionality and handling of the product. In view of the wide range of possible applications of the product, and because of the many variables and requirements associated with any particular implementation, HMS Networks cannot assume responsibility or liability for actual use based on the data, examples or illustrations included in this document nor for any damages incurred during installation of the product. Those responsible for the use of the product must acquire sufficient knowledge in order to ensure that the product is used correctly in their specific application and that the application meets all performance and safety requirements including any applicable laws, regulations, codes and standards. Further, HMS Networks will under no circumstances assume liability or responsibility for any problems that may arise as a result from the use of undocumented features or functional side effects found outside the documented scope of the product. The effects caused by any direct or indirect use of such aspects of the product are undefined and may include e.g. compatibility issues and stability issues.

Table of Contents

1. Introduction to Intesis MAPS	1
2. Prerequisites	2
3. Installation	3
4. First steps in Intesis MAPS	4
4.1. Latest News and Updates	4
4.2. Getting Started	6
5. Create a New Project from a Template	9
6. Saving, Opening, Importing, and Exporting the Project	10
7. Main Menu Overview	12
8. Connection Tab	13
9. Configuration Tab	15
9.1. General Configuration Menu	15
9.1.1. General Configuration	16
9.1.2. Connection	16
9.1.3. Conversions	17
9.1.3.1. Enabling Conversions in a Signal	19
9.1.4. Time Configuration	21
9.1.5. Security	21
9.1.6. Wiring Diagram	22
9.2. BMS Protocol: Modbus	23
9.2.1. Modbus Configuration	23
9.2.2. TCP Configuration	24
9.3. BMS Protocol: BACnet	25
9.3.1. BACnet Server General Configuration	25
9.3.2. Gateway Mode	26
9.3.3. BACnet Advanced Configuration	26
9.3.3.1. Notification Class	26
9.3.3.2. Binary Active/Inactive Text	30
9.3.3.3. Multistate States	31
9.3.3.4. Calendars	33
9.3.3.5. Schedules	34
9.3.3.6. Trend Logs	37
9.3.3.7. BACnet Description	39
9.3.3.8. Charset Configuration	39
9.4. Device Protocol: M-Bus	40
9.4.1. M-Bus Scan	40
9.4.1.1. Scan Configuration	41
9.4.1.2. Scan Discovery	43
9.4.1.3. Scan Results	44
9.4.1.4. Importing Newly Discovered Meters and Registers	45
9.4.2. M-Bus Meters Configuration	47
10. Signals Tab	52
10.1. Adding and Deleting Signals	53
10.2. Editing Signals	55

- 11. Receive/Send Tab 57**
- 12. Diagnostic Tab 58**
- 13. Late Configuration: Change the Gateway's Protocol 61**

1. Introduction to Intesis MAPS

Intesis MAPS® is a software tool for configuring and monitoring the Intesis® gateways. Intesis MAPS has been designed and developed in-house, assuring an up-to-date tool to get all the potential of Intesis gateways.

**NOTE**

Intesis MAPS is compatible with Windows® 7 and higher.

The design of this configuration tool focuses on four main pillars:

- A user-friendly interface.
- Multiple ways to create your project:
 - From scratch, using a template.
 - Importing data from your computer.
 - Downloading the settings from an already configured gateway.
- Full linkage between the control system and the device installation signals.
- Real-time monitoring of the device network.

2. Prerequisites

To configure the gateway, you need:

- The items supplied by HMS Networks:
 - Intesis IN712MEB***0000 gateway

**NOTE**

*** defines the gateway capacity.

- Gateway documentation:
 - Installation Guide
 - User Manual
- An Ethernet cable.
- A computer to run the configuration tool Intesis MAPS.

**NOTE**

Requirements:

- Windows 7 or higher
- Hard disk free space: 1 GB
- RAM: 4 GB

3. Installation

Downloading the software

1. Enter the [Intesis MAPS webpage](#).
2. Click the **Download now** button. The page will scroll down to the download form.
3. Fill out the form.

**NOTE**

You can review the [privacy policy section](#) for more information about how HMS processes the form data.

4. Click the **Download** button.
5. A .zip file will be downloaded to your computer.


Installing the software

1. Click the .zip file to open it.
2. Double-click the EXE file.
3. The Intesis MAPS Setup Wizard will guide you through the steps required to install Intesis MAPS on your computer:
 - a. Read the license agreement and select **I Agree**.
 - b. Select the installation folder.
4. Once the installation is completed, click the **Close** button.

4. First steps in Intesis MAPS


Upon launching Intesis MAPS, you will be greeted with the home screen. This window is divided into two sections: The **Getting Started** column on the left and the **Latest News and Updates** section in the main body.

Figure 1. Intesis MAPS home screen



4.1. Latest News and Updates


This section contains useful information related to Intesis MAPS.



Through this section, you can:

- Get access to an Intesis MAPS online course in the top section.
- Get information about features under consideration for implementation, planned, or recently launched in the features board of the middle section.

Figure 2. Intesis MAPS Features board




NOTE

Click a feature to expand it and rate it. To share a feature, expand it, click the  icon, and click on **Copy private link**.

This board also gives the option to submit ideas and suggestions for future features. To submit an idea, click the  button and fill out the form.

Figure 3. Intesis MAPS feedback form



- You can also enter the HMS Support Portal by clicking the **HMS Support Portal** button at the bottom section.

4.2. Getting Started

This section allows direct access to some of the most commonly used features of Intesis MAPS. These are:

NEWS

- **Latest News and Updates:** Click this option to load the **Latest News and Updates** section.

START

- **Create New Project:** Click this option to open the **New Project** menu.



NOTE

To know more about creating a new project, consult the section [Create a New Project from a Template \(page 9\)](#).

- **Load Project:** Click this option to load an Intesis MAPS project (.ibmaps file) to Intesis MAPS.
 1. Use the new dialog to look for the file and select it.
 2. Click **Open** or double-click the file.
 3. The project will be loaded to Intesis MAPS.



NOTE

For more information about file management, consult the section [Saving, Opening, Importing, and Exporting the Project \(page 10\)](#).

- **Get Project from Device:** Click this option to import the Intesis MAPS project file (.ibmaps file) directly from a gateway.
 1. Connect the gateway to the computer.
 2. On the **Discovered Devices** dialog, select the way you connected the gateway:
 - a. **IP:** If you are using the **Ethernet Port** of the gateway.
 - b. **USB:** If you are using the **USB C** port of the gateway.
 3. Select the gateway name (for IP) or the computer COM port (for USB) from the list.



NOTICE

If the gateway name or the computer COM port does not appear, click the **Refresh** button.

If the problem persists, ensure the gateway and the computer are correctly connected.

4. Once selected, the options on the right will autofill.
5. Click **Import Project**.
6. Once downloaded, use the **Save file** dialog to type a name for the file and select a folder to save it.



NOTE

For more information on connecting the gateway to your computer, consult the section [Connection Tab \(page 13\)](#).

- **Config IP settings:** This section lists the discovered devices in the network. Select a gateway from the list to check its properties and to gain direct access to the **Identify** and **Edit** functions.

**NOTE**

These two functions are covered in the section [Connection Tab \(page 13\)](#).

- **Import Project From USB Host:** Opens a file browser to select an Intesis MAPS project file in USB MAPS Project format (.exmaps) to load.

**NOTE**

For more information about file management, consult the section [Saving, Opening, Importing, and Exporting the Project \(page 10\)](#).

RECENT

- **Recent:** A list of up to the last five projects loaded is available here. To load one of these last projects, click on its name.

IMPORT

- **Import Project From Linkbox.**

**NOTICE**

This option does not apply to the IN712MEB***0000 gateway.

UPDATES

- **Update Gateway Firmware:** Use this option to check for updates and load a new firmware version to your gateway.
 1. Click **Update Gateway Firmware**.
 2. On the **Discovered Devices** dialog, select the way you connected the gateway to your computer:
 - a. **IP:** If you are using the **Ethernet Port** of the gateway.
 - b. **USB:** If you are using the **USB C** port of the gateway.
 3. Select the gateway name (for IP) or the computer COM port (for USB) from the list.

**NOTICE**

If the gateway name or the computer COM port does not appear, click the **Refresh** button.

If the problem persists, ensure the gateway and the computer are correctly connected.

4. Once selected, the options on the right will autofill.
5. Click **Update Firmware**.
6. Follow the instructions.

**NOTE**

After creating or loading a project, the firmware manager is also available through the **Tools - Firmware** option in the top menu.

- **Software Update:** Click this option to update Intesis MAPS.
 - If you are already using the latest version available, a dialog appears informing you that the software is up to date.

– If there is a new version available, a dialog will show the information about the new version and three options:

- **Skip this version:** Click this option to avoid the software update.




IMPORTANT

Each new version of Intesis MAPS includes improvements, issue fixes, support for new products, etc. It is recommended to keep the software up to date.

- **Remind me later:** When clicking this option, a new dialog appears, allowing you to select the time lapse for the reminder or to download the update now.
- **Update:** The new software version will be downloaded to your computer, and the setup wizard will be launched.

LANGUAGE

- **Select language:** Click this option to change the language.
 1. Select a language from the dialog.
 2. Click **Save**.
 3. To apply the new selected language, close Intesis MAPS and open it again.



5. Create a New Project from a Template

1. Open Intesis MAPS.
2. Click **Create New Project** in the **Start** menu on the left.
You can create a project from scratch using a template. To find the appropriate template, filter the search by:
 - Clicking BACnet or Modbus on the protocol logos, depending on the desired configuration.
 - Typing the order code in the **Order Code** field.



NOTE

The order code is printed on the silver label placed on the gateway's right side.

- Looking for the **Project Name** on the list: IN-MBSTCP-MBUS for Modbus or IN-BACIP-MBUS for BACnet.

Figure 4. Three possibilities for the template selection

New Project

Select BMS Protocol

Select Template

Order Code:

Project Name	BMS Protocol	Device Protocol	Description	Gateway Order Code
IN-MBS-HI	Modbus Slave	Hitachi	Intesis Hitachi to Modbus Slave Gateway	IN778AIxxxx0000 IN778HIxxxx0000 INMBSHITxxxx0v00
IN-MBS-HS	Modbus Slave	Hisense	Intesis Hisense to Modbus Slave Gateway	IN778AIxxxx0000 IN778HIxxxx0000 INMBSHISxxxx0v00
IN-MBS-IR	Modbus Slave	IR	Intesis IR to Modbus Slave Gateway	INMB5UN20011000 INMB5UN20011100
IN-MBS-KNX	Modbus Slave	KNX	Intesis KNX to Modbus Slave Gateway	IN781K0xxxx0000 INMB5KN0xxxxv00
IN-MBS-MBUS	Modbus Slave	M-Bus	Intesis M-Bus to Modbus Slave Gateway	IN782HExxxx0000 INMB5HExxxxv00
IN-MBS-MD	Modbus Slave	Midea	Intesis Midea to Modbus Slave Gateway	IN778AIxxxx0000 IN778HIxxxx0000
IN-MBS-ME	Modbus Slave	Mitsubishi Electric	Intesis Mitsubishi Electric AC to Modbus ...	IN778AIxxxx0000 IN778HIxxxx0000 INMBSHITxxxxCv00
IN-MBS-MH	Modbus Slave	Mitsubishi Heavy Industries	Intesis Mitsubishi Heavy Industries to Mo...	IN778HIxxxx0000
IN-MBS-OCPP	Modbus Slave	OCPP	Intesis OCPP to Modbus Gateway	INMB5OCxxxxv00
IN-MBS-PA	Modbus Slave	Panasonic	Intesis Panasonic to Modbus Slave Gatew...	IN778AIxxxx0000 - IN771PAxxxx0v00 IN778PAxxxx0000 - INMB5PAxxxx0v00 IN771AIxxxx0v00
IN-MBS-ROUTER	Modbus Slave	Modbus Router	Intesis Modbus Router	INMB5RTxxxx0000
IN-MBS-SM-CC	Modbus Slave	Samsung Cascade Control...	Intesis Samsung Cascade Controller to M...	IN788SAHXS0000
IN-MBS-SM	Modbus Slave	Samsung NASA	Intesis Samsung NASA to Modbus Slave G...	IN778AIxxxx0000 IN778SAxxxx0000 INMB5SAxxxx0v00
IN-MBS-YO	Modbus Slave	York	Intesis York to Modbus Slave Gateway	IN778AIxxxx0000 IN778YRxxxx0000
IN-MBSTCP-MBUS	Modbus Slave	M-Bus	Intesis M-Bus to Modbus TCP Server Gate...	IN712HExxxx0000 INMB5HExxxxv00

Device model

Available Licenses
20 Meters
50 Meters

Order Codes
IN712HEB020000
IN712HEB050000

3. Select the desired template.
4. Click **Next** or **double-click the template** on the list.




NOTE

Templates are just a starting point for your integration. Depending on the type of integration, you may have to modify some parameters.

6. Saving, Opening, Importing, and Exporting the Project

After editing any option from the **Configuration** and **Signals** tabs, an asterisk appears to indicate that you have made changes to the project but have not saved them or sent the project to the gateway yet:



To know how to send your project to the gateway, see [Receive/Send Tab \(page 57\)](#).

• SAVING YOUR INTESIS MAPS PROJECT




IMPORTANT

Remember to save your project periodically to keep your changes.

1. Click **Project**.

Figure 5. Project tab from the top menu



2. Click **Save** or **Save As**.



TIP


Instead, you can use the shortcut **Ctrl+S** (Save) or **Ctrl+Alt+S** (Save As).

3. On the **Save file** menu, type a **File name** and select where to save the file.
4. Click **Save**.

- **OPENING AN INTESIS MAPS PROJECT FROM YOUR COMPUTER**

**TIP**

Double-click a .ibmaps file saved on your computer to automatically open it in Intesis MAPS.



1. Click **Project**.
2. Click **Load**.
3. On the emergent window, select the desired file from your computer.
4. Click **Open**.

7. Main Menu Overview


Figure 6. Intesis MAPS main menu



The following sections provide an overview of the five tabs that compose the Intesis MAPS main menu. Through these options, you will establish a connection between the gateway and the computer, set up your project through the **Configuration** and **Signals** tabs, send it to the gateway, and monitor that everything works fine using the **Diagnostic** tab.


 **TIP**
Tooltip: Hover the cursor over a field, and a message will appear indicating the purpose of the parameter.

Figure 7. Example of a tooltip



8. Connection Tab

Figure 8. Connection tab window



1. Connect the gateway to your computer through the **Ethernet port**. Use an Ethernet CAT5 or higher cable.
2. On the **Connection Type** parameter, select **IP**.

! **IMPORTANT**
The default password is **admin**

! **IMPORTANT**
Make sure you have an internet connection.

📝 **NOTE**
The gateway's name may appear:

- **In black:** The gateway is compatible with the selected template.
- **In red:** The gateway is not compatible with the selected template.

- a. Select your gateway from the **Discovered Gateways** list.

Connection Parameters

Connection Type IP USB Port

Discovered Gateways

IN-MBS-BAC	Description	Value
IN-ASCII-BAC	Gateway Name	IN-BACIP-MBUS
IN-BACIP-MBUS	Serial Number	000R24714



NOTE
The **Value** column will autofill when the correct gateway is selected.


- b. Click the **Connect** button.

Gateway IP : Port Pwd:



NOTE
If your gateway doesn't match the selected template, a warning message will pop up.

- Go back to **Home** and ensure you selected the correct template.



The IN712MEBxxx0000 gateway is compatible with the following templates:

- For BACnet: IN-BACIP-MBUS
- For Modbus: IN-MBSTCP-MBUS
- If the problem persists, try to update the gateway's firmware as explained in [Getting Started → UPDATES → Update Gateway Firmware \(page 7\)](#).

When selecting IP as the connection type, two additional buttons will appear:

- **Identify:** Click the **Identify** button to make the gateway's LEDs blink for 10 seconds.
- **Edit:** Click the **Edit** button to open the **Config IP settings** window.

Config IP settings

Description	Value
Mac Address	CC:3F:1D:02:A2:C0
IP Address	10.113.51.238
NetMask	255.255.252.0
Gateway	10.113.48.5
Is DHCP	<input type="checkbox"/>

Password

You can edit the **IP Address**, **NetMask**, and Default **Gateway IP**.



NOTE
These parameters can also be edited in the **Configuration** tab. See [Connection \(page 16\)](#).

9. Configuration Tab


A menu with some options appears on the left side of the window:



- **General:** Configure the general parameters of the gateway.
- **BMS Protocol:** Modbus or BACnet, depending on the selected template. In the case of the image on the left, the control system is based on Modbus.
- **M-Bus:** Configure the parameters for the M-Bus installation.

9.1. General Configuration Menu

Figure 9. General configuration menu on the Configuration tab



Use this menu to configure some general parameters of the gateway.

9.1.1. General Configuration

- **Gateway Name:** Type a descriptive name for your gateway (max. 32 characters).
- **Project Description:** Type a short description of your project (max. 255 characters).

9.1.2. Connection



NOTE

When commissioning the gateway for the first time, DHCP will be enabled for 30 seconds. During that time, an IP address will be automatically assigned to the gateway if there is a DHCP server. If there is no DHCP, you can type an IP address of your choice. After that time, the default **IP address 192.168.100.246** will be automatically set.

You can find this default IP address written in the installation guide: **Communication ports** table → **Ethernet**.

- **Enable DHCP (selected by default):** Keep this option selected for networks that have a DHCP server. Deselect this option to edit the following parameters:
 - **IP Address:** Assign a fixed IP address for the gateway.
 - **Net Mask:** Set the gateway IP netmask.
 - **Default Gateway:** Type the IP for the default gateway.




NOTE

The **Default Gateway** parameter is a networking concept not related to the Intesis gateway. It refers to the IP address of the device (usually a router) that serves as the access point for sending data from the local network to other networks, including the Internet. Therefore, this field only needs to be filled in if the Intesis gateway to be configured is connected outside the local network.

- **Password.** Follow these instructions to set a new password for the gateway:
 1. Click the **Change** button.
 2. Type a new password.
 3. Go to the **Receive/Send** tab.
 4. In the **Send** menu, click the **Send** button.
 5. Go to the **Connection** tab.
 6. Select the gateway from the **Discovered Gateways** window.
 7. Click **Connect**.

9.1.3. Conversions

Click the **Edit** button to open the **Conversions Manager**.



Use this menu to create and configure filters and operations to be applied to any signal later.

Filters:

By default, five filters appear listed:

- **Limit to 0-100**
- **Limit to 0-255**
- **Is not 0**
- **Is higher than 100**
- **Only positive values**

Click the **+** button to add more filters.

Select a filter and click the **–** button to delete it.

For each filter, you can set:

- **Filter Name:** Type a name for the filter.
- **Type:** Select the filter type.
 - **Comparison**
 - **Non-limited Filter**
 - **Limited Filter**

- **Comp. Type:** Set the comparison type for this filter and set the value(s) to complete each formula.
 - **Equal:** $X ==$ Set a value
 - **Different:** $X !=$ Set a value
 - **Less:** $X <$ Set a value
 - **Greater:** $X >$ Set a value
 - **InRange:** Set a value $\leq X \leq$ Set a value
 - **OutOfRange:** $X <$ Set a value or $X >$ Set a value

Operations:

By default, 10 operations appear listed:

- **Celsius to Fahrenheit**
- **Fahrenheit to Celsius**
- **x 10**
- **/ 10**
- **x 100**
- **/ 100**
- **x 1000**
- **/ 1000**
- **0-100 to 0-255**
- **0-255 to 0-100**

Click the + button to add more operations.

Select an operation and click the – button to delete it.

For each operation, you can set:

- **Operation Name:** Type a Name for the operation.
- **Type:** Choose Scale or Arithmetic.

Scale

Set the **Values** for:

- **minimum Input / maximum Input**
- **minimum Output / maximum Output**

Arithmetic

Considering the **Definition** formula $y = x \times B \times (10^A) + C$, set the **Values** for:

- **A**
- **B**
- **C**

Click **Save** to save the changes.

9.1.3.1. Enabling Conversions in a Signal



NOTICE

To better understand this topic on conversions, we are moving from the **Configuration** tab to the **Signals** tab.

Once the needed filters and operations are created and configured, follow these steps to enable them in a signal:

1. Go to the **Signals** tab.
The **Conversions** column is at the end.

#	Active	Description	Modbus Slave				M-Bus				Conversions		
			D...	For...	Ad...	Bit	Read / ...	Device	M-Bus Code	Register		Magnitude	Units
23	<input checked="" type="checkbox"/>	Manufacturer error Device 1	16	0: Un...	33	-	0: Read	Meter 2	5: M-BUS Status	-	-	-	-
24	<input checked="" type="checkbox"/>	Comm Error Device 2	16	0: Un...	34	-	0: Read	Meter 3	0: Comm Error	-	-	-	-
25	<input checked="" type="checkbox"/>	Force reading Device 2	16	0: Un...	35	-	2: Read ...	Meter 3	4: Force Devic...	-	-	-	-
26	<input checked="" type="checkbox"/>	Timestamp Device 2	64	0: Un...	36	-	0: Read	Meter 3	8: Timestamp	-	-	-	-
27	<input checked="" type="checkbox"/>	Serial number Device 2	32	0: Un...	40	-	0: Read	Meter 3	7: Meter Serial ...	-	-	-	-
28	<input checked="" type="checkbox"/>	Application error Device 2	16	0: Un...	42	-	0: Read	Meter 3	5: M-BUS Status	-	-	-	-
29	<input checked="" type="checkbox"/>	Power low Device 2	16	0: Un...	43	-	0: Read	Meter 3	5: M-BUS Status	-	-	-	-
30	<input checked="" type="checkbox"/>	Permanent error Device 2	16	0: Un...	44	-	0: Read	Meter 3	5: M-BUS Status	-	-	-	-
31	<input checked="" type="checkbox"/>	Temporary error Device 2	16	0: Un...	45	-	0: Read	Meter 3	5: M-BUS Status	-	-	-	-
32	<input checked="" type="checkbox"/>	Manufacturer error Device 2	16	0: Un...	46	-	0: Read	Meter 3	5: M-BUS Status	-	-	-	-
33	<input checked="" type="checkbox"/>	Energy Device 0	64	0: Un...	47	-	0: Read	Meter 1	6: Measure	1	-	-	-
34	<input checked="" type="checkbox"/>	Volume Device 0	16	0: Un...	51	-	0: Read	Meter 1	6: Measure	2	-	-	-
35	<input checked="" type="checkbox"/>	Temperature Device 0	16	0: Un...	52	-	0: Read	Meter 1	6: Measure	3	-	-	-
36	<input checked="" type="checkbox"/>	Energy Device 1	64	0: Un...	53	-	0: Read	Meter 2	6: Measure	1	-	-	-
37	<input checked="" type="checkbox"/>	Volume Device 1	16	0: Un...	57	-	0: Read	Meter 2	6: Measure	2	-	-	-
38	<input checked="" type="checkbox"/>	Temperature Device	16	0: Un...	58	-	0: Read	Meter 2	6: Measure	3	-	-	-
39	<input checked="" type="checkbox"/>	Energy Device 2	64	0: Un...	59	-	0: Read	Meter 3	6: Measure	1	-	-	-



NOTICE


If the **Conversions** column does not appear, use the **Edit Columns** button from the bottom menu to enable it.

Select Visible Columns

Common	Modbus Slave	M-Bus
<input checked="" type="checkbox"/> #	<input checked="" type="checkbox"/> Data Length	<input checked="" type="checkbox"/> De
<input checked="" type="checkbox"/> Active	<input checked="" type="checkbox"/> Format	<input checked="" type="checkbox"/> M-
<input checked="" type="checkbox"/> Description	<input checked="" type="checkbox"/> Address	<input checked="" type="checkbox"/> Re
<input checked="" type="checkbox"/> Conversions	<input checked="" type="checkbox"/> Bit	<input checked="" type="checkbox"/> M:
	<input checked="" type="checkbox"/> Read / Write	<input checked="" type="checkbox"/> Un


2. Choose the signal you want to apply the conversion to and click the button at the end. The **Select Conversions** window appears.

3. Use the dropdown menus to choose the needed filters and operations.



NOTICE
 The direction of the conversion depends on the type of the selected object and is indicated by the black arrows.
 This also determines the active text input in the **Test** section.

For example, if you have an M-Bus temperature meter reporting the value in degrees Fahrenheit and you want to convert it to degrees Celsius, use the second dropdown menu starting from the right to select the desired operation:



4. Test the configuration by writing a value in the appropriate option and clicking the **Check** button. For example, we typed **87** (degrees Fahrenheit) in the **M-Bus Value** option, which is converted to **30.51**(degrees Celsius) in the **Modbus Slave Value** option.
5. Click **Save** to apply the changes. The word **Enabled** appears in the **Conversions** column for the signals with an assigned conversion.

9.1.4. Time Configuration

- **Set current PC time to the gateway:** Connect the gateway to your computer and click the **Set** button to set the gateway's time to your computer's current time.
- **Time sync on project download** (disabled by default): The gateway's time is set to your computer's time when downloading the project to the gateway.

9.1.5. Security

- **Edit Security Configuration:** Click the **Edit** button to open the **Security Configuration** window.



IMPORTANT


We recommend keeping the predetermined configuration.

- **Disable UPD Discover Service** (disabled by default): If selected, the gateway is not discoverable through UDP communication.
- **Disable TCP Console Service** (disabled by default): If selected, the gateway stops communicating with the configuration and diagnostic software through TCP. This only applies to gateways supporting connection to the computer via both Ethernet and console ports.
- **Use custom UDP/TCP port** (disabled by default): If selected, you can set the UDP/TCP port through the parameter below.
- **Disable HTTPS Certificates Auto Update** (enabled by default): If selected, automatic updates for the HTTPS certificates are not allowed. If deselected, you can set the update time period using the parameter below.

Click **Save** to save the changes.

9.1.6. Wiring Diagram

- **Check Gateway's Wiring Diagram:** Click the **View** button to open the schematic image on how to wire the gateway.



9.2. BMS Protocol: Modbus

Figure 10. Modbus configuration parameters

The screenshot shows the Intesis MAPS software interface. The top navigation bar includes 'Home', 'Project', 'Tools', 'View', and 'Help'. Below this are icons for 'Connection', 'Configuration', 'Signals', 'Receive / Send', and 'Diagnostic'. The 'Intesis MAPS' logo is on the right. The main content area is divided into 'General' and 'M-Bus' sections. The 'Modbus Slave' tab is highlighted with a red box. The 'Modbus Configuration' section includes:

- Type: TCP (dropdown)
- Byte Order 32 bits registers: Big Endian (dropdown)
- Notification on MB Write: Always, On Change of Value
- Select Modbus register base: 0 based (dropdown)

 The 'TCP Configuration' section includes:

- Port: 502 (spin box)
- Keep Alive: 10 (spin box) mins
- Slave Number: 1 (spin box)

9.2.1. Modbus Configuration

- **Type:** TCP is selected by default.
- **Byte Order 32 bits registers:** Select the byte order for the BMS configuration.
 - Big Endian
 - Little Endian
 - Word Inv BE (Word Inverted Big Endian)
 - Word Inv LE (Word Inverted Little Endian)
- **Notification on MB Write:** Select when to send Modbus writing notifications to the device protocol.
 - Always
 - On Change of Value (default value)
- **Select Modbus register base:** Select the Modbus addressing type.
 - 0 based (default value)
 - 1 based

9.2.2. TCP Configuration

- **Port:** Set the port for communication between the gateway and the Modbus TCP system (1 .. 65535).

**NOTE**

The default port is 502.

- **Keep Alive:** Set the time in minutes before sending a keep-alive message (1 .. 1440. Default value: **10 minutes**).

**NOTE**

Set the parameter to 0 to disable this function.

- **Slave Number:** Set the server address (1 .. 255. Default value: **1**).

9.3. BMS Protocol: BACnet

Figure 11. BACnet configuration parameters

The screenshot displays the Intesis MAPS configuration interface. The top navigation bar includes 'Home', 'Project', 'Tools', 'View', and 'Help'. Below this, there are five main menu items: 'Connection', 'Configuration', 'Signals', 'Receive / Send', and 'Diagnostic'. The 'Configuration' menu is active, and the 'BACnet Server' option is highlighted with a red box. The main content area is titled 'BACnet Server General Configuration' and contains the following sections:

- General:**
 - Device Name: Device IN-BACIP-MBUS
 - Device Instance: 246
 - Password: (empty) [Change] Disable BACnet password (not recommended)
 - Objects Information: [Show]
- Gateway Mode:**
 - Mode: IP
 - UDP Port: 47808
 - Network Role: Disabled
 - Show Advanced Configuration
- Notification Class:** [Edit]
- Binary Active/Inactive Text:** [Edit]
- Multistate States:** [Edit]
- Calendars:** [Edit]
- Schedules:** [Edit]
- Trend Logs:** [Edit]
- BACnet Description:** [Edit]
- Charset Configuration:** Select charset format: UTF 8

9.3.1. BACnet Server General Configuration

- **Device Name:** Type a descriptive name for your gateway.
- **Device Instance:** Set the BACnet device object instance property. This is a unique identifier for the gateway inside a single BACnet network segment (0 to 4194302. Default value: **246**).
- **Password:** Click the **Change** button and follow the instructions to set a password for the gateway.
- **Objects Information:** Click **Show** to see a table with the type of objects available.

- **Disable BACnet password (not recommended)** (parameter disabled by default): Disable the BACnet password.

**IMPORTANT**

Keep the BACnet password enabled to ensure the security of the gateway and the installation.

9.3.2. Gateway Mode

- **Mode:** IP mode is selected by default.
- **UDP Port:** Select the UDP port for the BACnet/IP communication (1 .. 65535).

**NOTE**

The UDP port is set to 47808 (BAC0 in hexadecimal) by default.

- **Network Role:** Define the gateway behavior regarding other network elements.

**IMPORTANT**

If you are unfamiliar with these options, please leave the parameter as **Disabled** to avoid issues with the BACnet communication/configuration.

- **Disabled:** The gateway provides no special service regarding network communication or settings.
- **Foreign Device:** The gateway acts as a foreign device from the BACnet network point of view.
- **BBMD:** The gateway acts as a BBMD in the BACnet network.

9.3.3. BACnet Advanced Configuration

Show Advanced Configuration: Open advanced configuration parameters (disabled by default).

**IMPORTANT**

These menus provide advanced functionalities intended for expert users.

We recommend keeping these options set to their default values.

9.3.3.1. Notification Class

Click **Edit** to open the **Notification Class Configuration** parameters.

Figure 12. Notification Class Configuration window

Click the **+** button to create up to ten Notification_Class objects. For each one, you can set:

- **Object Name:** Type a name for the Notification_Class.
- **Object Instance:** Set the BACnet object instance for the Notification_Class.
- **Recipient List:** Click the **+** button to create up to eight different BACnet destinations. For each one, you can set:
 - **Destination Name:** Type a descriptive name for the BACnet destination.
 - **Transitions:** Select which transitions will force this Notification_Class to be active:
 - **Off_Normal** (disabled by default): When the status changes from off to normal.
 - **Fault** (disabled by default): When the status changes to fault.
 - **Normal** (disabled by default): When the status changes from fault to normal.
 - **Recipient Type:** Select the type of destination:
 - **Device** (default value): The recipient is a device.
 - **Object Instance:** Select the device instance number for this device.
 - **Address (IP):** The recipient is set using the specific address on BACnet/IP. Specify:
 - **Network Number** (0 .. 65535. Default value: 0).
 - **IP address** (192.168.100.10 by default) and **Port** (47808 by default) for the destination.
 - Set the destination as a **Global Broadcast** (disabled by default).
 - Set the destination as a **Broadcast** (disabled by default).

- **Address (MS/TP):** The recipient is set using the specific address on BACnet MS/TP. You'll have to specify:
 - **Network Number** (0 .. 65535. Default value: **0**).
 - **MS/TP MAC Address** (0 .. 255. Default value: **0**).
 - Set the destination as a **Global Broadcast** (disabled by default).
 - Set the destination as a **Broadcast** (disabled by default).
- **Address (Other):** The recipient is set using another type of address. You'll have to specify:
 - **Network Number** (0 .. 65535. Default value: **0**).
 - **Other Address** (HEX string. Default value: **ff**).
 - Set the destination as a **Global Broadcast** (disabled by default).
 - Set the destination as a **Broadcast** (disabled by default).
- **BACDestination Advanced Options** (disabled by default): Check this option to show some advanced options.
 - **Valid days:** Sets the days for receiving the notification.
 - **From:** Sets the starting point for the valid period.
 - **To:** Sets the ending point for the valid period.
 - **Issue Confirmed Notifications** (disabled by default): Determines if notification events are sent as Confirmed or Unconfirmed to the BACnet destination.

**IMPORTANT**

Sending them as Confirmed requires Ack.

- **Notification Class Advanced Options** (disabled by default): Check this option to show the **Ack Required** options.
 - **Off_Normal** (disabled by default): Enable the acknowledgment for the TO_OFF_NORMAL event.
 - **Fault** (disabled by default): Enable the acknowledgment for the TO_FAULT event.
 - **Normal** (disabled by default): Enable the acknowledgment for the TO_NORMAL event.

**NOTE**

Set the priority for each parameter (0 .. 255. Default value: **140**).

After creating and configuring the needed Notification_Class objects, the next step is to assign them to signals:


**NOTICE**

To better understand the assignment of Notification_Class objects to signals, we are moving from the **Configuration** tab to the **Signals** tab.


1. Go to the **Signals** tab.



- Click the **Edit Columns** button from the bottom menu.




- In the **Select Visible Columns** window, select **NC**.
- Click **Save**.




A new column named **NC** is now visible.

- Look for the signal to which you want to assign the Notification_Class object and click the corresponding cell in the NC column.



- Click the button.
- In the **Select Notification Class** window, uncheck the **Empty** parameter.
- Use the dropdown menu to select the Notification_Class object.



9. Set the rest of the parameters:

**NOTE**

These parameters vary depending on the signal type.

- **Notify Type:** Choose if the notification is sent as an **Alarm** (default) or an **Event**.
- **Time Delay:** Set the time in seconds before launching the notification (0 .. 65535. Default value: **0 seconds**).
- **Event Enable:** Click in the field to enable/disable the following options:
 - **TO_OFF_NORMAL** (enabled by default): Enable/disable the TO_OFF_NORMAL event.
 - **TO_FAULT** (enabled by default): Enable/disable the TO_FAULT event.
 - **TO_NORMAL** (enabled by default): Enable/disable the TO_NORMAL event.
- **Feedback Value:** Choose if the feedback value is **Active** or **Inactive** (default).
- **High Limit** (Disabled by default): Enable this parameter to set the high limit for the notification.
- **Low Limit** (Disabled by default): Enable this parameter to set the low limit for the notification (0.00 .. 999.00).
- **Deadband:** Set the deadband for the notification.

10. Click **Save** to save the changes.

Once assigned, the instance number of the Notification_Class object appears in the **NC** column.

18	<input checked="" type="checkbox"/>	Timestamp Device 2	46: LAV	5	no_u...	-	Met
19	<input checked="" type="checkbox"/>	Serial number Devi...	46: LAV	6	no_u...	-	Met
20	<input checked="" type="checkbox"/>	Status M-BUS Device...	0: AI	2	no_u...	-	Met
21	<input checked="" type="checkbox"/>	Device 0 Energy	46: LAV	7	no_u...	6	Met
22	<input checked="" type="checkbox"/>	Device 0 Voltage	0: AI	3	no_u...	-	Met
23	<input checked="" type="checkbox"/>	Device 0 Temperature	0: AI	4	no_u...	-	Met
24	<input checked="" type="checkbox"/>	Device 1 Energy	46: LAV	8	no_u...	-	Met

9.3.3.2. Binary Active/Inactive Text

Use this menu to create new text pairs for binary-type objects, edit existing ones, or delete unused pairs.

1. Click **Edit** to open the **Binary Active/Inactive Text** editor.
2. Click any text cell to edit its content. The maximum length for any text is 24 characters.
3. Type the desired text.
4. **+**: Add a new row to the table.

**NOTE**

You can add up to 100 string pairs.

5. **-**: Delete the selected row from the table.
6. Click **Save** to save the changes.

After creating or editing the desired text pairs, the next step is to assign them to the corresponding binary-type signals. To do so, select **Texts** as a visible column in the **Signals** tab.



NOTICE

For more information on adding visible columns to the Signals tab, refer to [Steps 1 to 3 of the Notification Class section \(page 28\)](#). In this case, however, select the **Texts** column from the BACnet Server section instead of **NC**.

Having done that, click the three-dotted button on the **Texts** cell of any binary object to invoke the **Binary State Selector** window. Select the desired option. Once the assignment is complete, the currently selected text pair appears in the corresponding **Texts** column of the **Signals** tab.

BACnet Server						
Name	Type	Instance	Units	NC	Texts	
General Comm Error	3: BI	0	-	-	3: Yes; No	

9.3.3.3. Multistate States

Use this menu to create state text lists to be applied to Multistate Objects.

1. Click **Edit** to open the **Multistate State Manager**.

Multistate State Manager

State Text Configuration

Create new State Text or modify the current ones

#	Num Elements	Text State 1	Text State 2	Text State 3	Text State 4	Text State 5
0	2	On	Off			
1	5	State text 1	State text 2	State text 3	State text 4	State text 5

+ -

Mapping Configuration

Create new Mapping configurations or modify the current ones

#	Num Of States	Default State	Value State 1	Value State 2	Value State 3	Value State 4	Value State 5	Value State 6
0	2		1 5	4				
1	6		5 10	11	12	13	14	15

+ -

Save Cancel

- a. Use the **State Text Configuration** table to create new state text lists or modify existing lists.
 - b. Use the **Mapping Configuration** table to create a secondary mapping for the states to create custom conversions between the BACnet states received and the values that the gateway will transmit to the BMS protocol.
2. Click any cell in either table to edit its text.
 3. Type the desired text. The maximum length for any state text is 24 characters.

4. **+**: Add a new row in the table above the button.

**NOTE**

You can add up to 100 lists, each one with a maximum of 100 elements.

5. **—**: Delete the selected row of the table above the button.
6. Click **Save** to save the changes.

After creating or editing the desired state texts, the next step is to assign them to the corresponding multistate-type signals. To do so, select **Texts** as a visible column in the **Signals** tab.

**NOTICE**

For more information on adding visible columns to the **Signals** tab, refer to [Steps 1 to 3 of the Notification Class section \(page 28\)](#). In this case, however, select the **Texts** column from the **BACnet Server** section instead of **NC**. The **# States** column can also be added to provide additional information.

Having done that, click the three-dotted button on the **Texts** cell of any multistate object to invoke the **Multi State Selector** window. Select the desired option. Once the assignment is complete, the currently selected state texts appear in the corresponding **Texts** column of the **Signals** tab.

BACnet Server						
Name	Type	Instance	Units	Texts	# States	
Force Bus Reading	14: MO	0	-	2: Normal operation; Force Read Once(...)	4	

**NOTICE**

If the **# States** column is also visible, it will display the number of elements of the currently selected state text. Alternatively, the **# States** column can also be used to enter the number of elements for the currently selected object manually, but only when no state texts are being used.

9.3.3.4. Calendars

Click **Edit** to open the **Calendars Configuration** parameters.

Figure 13. Calendars Configuration window

Click the **+** button to create up to 10 calendars. For each one, you can set:

- **Object Name:** Type a name for this calendar.
- **Object Instance:** Set the BACnet object instance for the calendar (0 .. 4194303. Default value: 0).
- **Calendar Entries:** Click the **+** button to determine the number of calendar entries (patterns). Create up to 32 different entries per calendar. For each entry, you can set:
 - **Entry Name:** Type the name for that pattern.
 - **Type:** Set the date type for that pattern:
 - **Date** (default value): The pattern applies to a specific day.
 - **Date Range:** The pattern applies within a date range. Set the starting day (**From**) and the ending day (**To**).
 - **Week N Day:** The pattern applies to a specific **Month**, **Week of the Month**, and/or **Day of the Week**.



NOTE

Select an asterisk (*) to apply the rule to all cases, i.e., an asterisk in the **Month** option will make the pattern apply to every month.

9.3.3.5. Schedules

Click **Edit** to open the **Schedules Configuration** parameters.

Click the **+** button to create up to ten schedules. For each one, you can set:

- **General Configuration:**

- **Name:** Type a name for this schedule.
- **Object Instance:** Set the BACnet object instance for the schedule (0 .. 4194303. Default value: **0**).
- **Schedule Type:** Set it as an **Analog** (default), **Binary**, **Multistate**, or **Large Analog** object.



IMPORTANT

Use the type that best suits this particular schedule. For example, if this schedule is used to turn a device ON, select **Binary**.

- **Priority for Writing:** Select the writing priority of the schedule value (1 .. 16. Default value: **16**).
- **Schedule Default:** Set the default value for the schedule.




NOTICE

The range of values allowed depends on the type of object previously selected:


- **Analog:** 0.00 .. 65535.00
- **Binary:** 0, 1
- **Multistate:** 0 .. 65535
- **Large Analog:** 0.00 .. 65535.00

- **Effective Period:** Set the starting and ending date. The schedule will be in effect during this period.

- **Objects Configuration:** Include BACnet objects in a specific schedule.



- **Schedule Type:** It shows the previous **Schedule Type** object you selected: Analog, Binary, Multistate, or Large Analog.
- **List of Object References:** Click the **+** button to open the **Objects Selection** dialog. The background color of each object indicates its status as follows:
 - **Grey:** Not allowed. This object type does not match the **Schedule Type** you previously selected.
 - **Yellow:** Allowed.
 - **Orange:** Already applied.
- **Weekly Schedule Configuration:**



- **Select Day:** Select which day of the week the schedule applies.
- **Time Values:** Click the **+** button to create up to six time periods. For each one, set the **Start Time**, the **End Time**, and the **Value**.

- **Exception Events Configuration:** Create exceptions to the schedules.

The screenshot shows the 'Schedules Configuration' window with the 'Exception Events' tab selected. On the left, a list of schedules (Schedule_0 to Schedule_4) is shown, with Schedule_4 selected. In the center, an 'Exception Events List' contains Exception_0, Exception_1, Exception_2, and Exception_3, with Exception_3 selected. On the right, the configuration for Exception_3 is displayed:

- Name:** Exception_3
- Event Priority:** 16
- Time Values:** 15:22->1, 22:22->1
- Exception Type:** Date Range (selected)
- From:** 16/2/2023/Thursday
- To:** 16/2/2023/Thursday
- Value Type:** Analog
- Start Time:** 22:22:24
- End Time:** End of Day
- Value:** 1.00

Buttons for '+', '-', 'Save', and 'Cancel' are visible at the bottom of the configuration area.

- **Exception Events List:** Click the **+** button to create up to 16 different exceptions. For each one, you can set:
 - **Name:** Type a name for the exception.
 - **Event Priority:** Set a priority for the exception (1 [maximum priority] .. 16 [minimum priority]. Default value: 16).
 - **Time Values:** Click the **+** button to create up to six time periods. For each one, set the **Starting Time**, the **End Time**, and the **Value**.
 - **Exception Type:** Set the type of date for the exception:
 - **Date** (default): Select a single day.
 - **Date Range:** Select a date range. Set the starting day (**From**) and the ending day (**To**). The exception will be in effect during this period.
 - **Week N Day:** Set the date by selecting a **Month**, a **Week of the Month**, and/or a **Day of the Week**.

**NOTE**


Select an asterisk (*) to apply the rule to all cases.

- **Calendar:** Select a Calendar to apply its values to the exception event.

**NOTE**

This option is only enabled when at least one Calendar has been previously created. See [Calendars \(page 33\)](#).

- **Calendar View:** Display a calendar to consult all the configured schedules.




You can also create and modify **Weekly** and **Exception** schedules from this menu:

1. Use the calendar miniatures on the left to select the desired week.
2. Use the schedule view on the right to select the desired day and hour.
3. Right-click to open the settings menu. From this menu, the following options are available:
 - **Create Weekly Schedule:** Create a new weekly schedule.
 - **Create Exception Schedule:** Create a new exception event.
 - **Settings:** Edit an already created weekly schedule or exception event.
 - **Delete Event:** Delete the selected weekly schedule or exception event.

9.3.3.6. Trend Logs

Click **Edit** to open the **Trend Logs** parameters.

Figure 14. Trend Logs Configuration window



Click the **+** button to create up to five trend logs. For each one, you can set:

- **Object Name:** Type a name for the trend log.
- **Object Instance:** Set the BACnet object instance for the trend log (0 .. 4194303. Default value: **0**).
- **Logging Type:** Select the trend log type:
 - **Polled** (default value): The trend log is triggered when polling.
Use the **Log Interval** parameter to set the poll cadence in seconds (1 .. 65535. Default value: **300 sec**).
 - **COV:** The trend log is triggered when there is a change of value.
Use the **Client COV Increment** parameter to set (0.00 .. 100000.00. Default value: **0.00**).
 - **Triggered:** The trend log is triggered by the BACnet system.
- **Enable** (enabled by default): Enable/disable the specific trend log even if the trend log is in the valid time range.
- **Stop When Full** (enabled by default):
 - If **enabled**, it will stop the trend log when the buffer is full.
 - If **disabled**, it will keep the last 2880 valid values.
- **Date Time Configuration:** Set the period when trend logs are active.
 - **Always** (default value).
 - **Range:** Use the **Start Time** and **End Time** parameters to set a time range.
- **Selected Objects (max 10):** Click the **+** button to include up to ten BACnet objects in a trend log. To remove previously added objects, use the **–** button.

Figure 15. BACnet Objects Selection

#	Object Name	BAC Type	BAC Instance
1	General Comm Error	3-BI	0
2	Force Bus Reading	5-BV	0
3	Activate Continuous Polling	5-BV	1
4	Bus Activity	3-BI	1
5	Gateway timestamp	46-LAV	0
6	Comm Error Device 0	3-BI	2
7	Force reading Device 0	5-BV	2
8	Timestamp Device 0	46-LAV	1
9	Serial number Device 0	46-LAV	2
10	Status M-BUS Device 0	0-AI	0
11	Comm Error Device 1	3-BI	3
12	Force reading Device 1	5-BV	3
13	Timestamp Device 1	46-LAV	3
14	Serial number Device 1	46-LAV	4
15	Status M-BUS Device 1	0-AI	1



NOTE

To select multiple items in both the **Selected Objects** and the **Objects Selection** tables, press and hold the **Shift** key when clicking for consecutive objects or the **Control** key for non-consecutive objects. Objects already added are shown with an orange background.

9.3.3.7. BACnet Description

Click **Edit** to open the **BACnet Description** window. You can add an editable **Description** column in the **Signals** tab table.

- **Disabled (By default):** The Description column is not added.
- **Enable BACnet Description (96 bytes):** The Description column is added, allowing a description up to 96 characters long.
- **Enable BACnet Description 255 bytes (only for licenses up to 1200 points):** The Description column is added, allowing a description up to 255 characters long.



NOTE


Some special characters may use three bytes each.

9.3.3.8. Charset Configuration

There are four character sets available:


- **UTF 8** (default value)
- **UCS 4**
- **UCS 2**
- **ISO 8859-1**

9.4. Device Protocol: M-Bus



9.4.1. M-Bus Scan

Scan M-Bus Network: Click **Scan** to open the **Scan M-Bus Network** window.



9.4.1.1. Scan Configuration

- **Reset to default scan values:** Click this button to reset all the options of this menu to their default values.
- **M-Bus Scan Mode:** Select the type of addressing on which you want to run the scan.
 - **Primary Address**
 - **Secondary Address (selected by default)**
 - **Single Device**
- **Primary Address Config:** Use this option to run the scan between a range of addresses.



NOTE

This option is only available if the **M-Bus Scan Mode** option is set to **Primary Address**.

- **Start Address:** Lower limit of the scan (0 .. 250. Default value: **0**).
- **End Address:** Higher limit of the scan (0 .. 250. Default value: **250**).
- **Baudrates:** Select the M-Bus meters baudrate, in bits per second (bps).
 - 300, 600, 1200, 2400, 4800, 9600 (Default value: **2400 bps**).



NOTE

You can select several values.



IMPORTANT

The scanning process will only find the M-Bus meters operating at the selected baudrates.

For example, to discover the following meters during the bus scan, you should select **1200 bps**, **2400 bps**, and **4800 bps**:

Scan Results							Meters: 1 / 3	
Meters Newly Detected								
Enabled	M-Bus Meter	Address	Identifier	Manufacturer ID	Version	Medium	Baudrates	
<input checked="" type="checkbox"/>	Meter 0	0	00579287	Acme	32	2: Electricity	2400	
<input checked="" type="checkbox"/>	Meter 1	1	12746519	Acme	32	2: Electricity	1200	
<input checked="" type="checkbox"/>	Meter 2	2	00286438	Acme	32	2: Electricity	4800	



NOTICE

Selecting several baudrates will make the scanning process take longer.



IMPORTANT

Once discovered, meters with different baud rates must be configured to use the same baud rate as the gateway.

- **Advanced Configuration:** Click **Advanced** to open the **Advanced Configuration** window.



IMPORTANT

This menu provides advanced functionalities intended for expert users.

We recommend keeping these options set to their default values.

Advanced Configuration

Interframe Time ms

Baudrate Timeout

Specify the timeout (ms) for each baudrate. This timeout will be used once the baudrate is selected

300 bps	<input style="width: 50px;" type="text" value="10500"/>
600 bps	<input style="width: 50px;" type="text" value="5500"/>
1200 bps	<input style="width: 50px;" type="text" value="3000"/>
2400 bps	<input style="width: 50px;" type="text" value="1500"/>
4800 bps	<input style="width: 50px;" type="text" value="1000"/>
9600 bps	<input style="width: 50px;" type="text" value="500"/>

Enable Deep Scan

Individual SND_NKE

Application Reset for Scan

Application Reset for Discovery

Subcode

- **Time Interframe:** Set the time, in milliseconds, to add to the standard minimum interframe time (0 .. 30000. Default value: **0 ms**).

**NOTE**

This value is used only during the scan process and does not apply after the process is complete.

- **Timeout for each baudrate:** Set a specific timeout, in milliseconds, for each previously selected baudrate.
 - **300 bps:** 500 .. 30000. Default value: **10500 ms**.
 - **600 bps:** 500 .. 30000. Default value: **5500 ms**.
 - **1200 bps:** 500 .. 30000. Default value: **3000 ms**.
 - **2400 bps:** 500 .. 30000. Default value: **1500 ms**.
 - **4800 bps:** 500 .. 30000. Default value: **1000 ms**.
 - **9600 bps:** 500 .. 30000. Default value: **500 ms**.

**NOTE**

These values are used only during the scan process and do not apply after the process is complete.

- **Enable Deep Scan (disabled by default):** Enable this option to run a refined scan.

**NOTICE**

When this option is disabled, the scan algorithm considers that a meter has been found after receiving a unique ACK with no collisions.

**NOTE**

This option is only available if the **M-Bus Scan Mode** option is set to **Secondary Address**.

When activating the **Enable Deep Scan** option, two more options appear:

- **Deep scan (selected by default):** This option forces the search to refine down to the last digit of the secondary address.
- **Deeper scan:** In addition to forcing the search to refine down to the last digit of the secondary address, this option also completes scanning the entire range where a meter has been found.
- **Individual SND_NKE (enabled by default):** The behavior of this option varies depending on the M-Bus Scan Mode.
 - The **M-Bus Scan Mode** option is set to **Primary Address**: An individual SND_NKE (initialization trigger) is added to each meter before starting the scan.
 - The **M-Bus Scan Mode** option is set to **Secondary Address**: This option adds addressing SND_NKE in the network layer (FDh).
- **Application Reset for Scan (disabled by default):** If enabled, this option sends an application reset to all the meters in the bus before the scan.
- **Application Reset for Discovery (disabled by default):** If enabled, this option adds an application reset subcode to all the meters found in the bus before discovering the meters signals. Use the dropdown menu below the option to select the desired subcode.

Click the **Apply** button to save the advanced configuration settings.

9.4.1.2. Scan Discovery

- **Meter to Registers discovery gap:** Set the waiting time, in seconds, between the meter scan and the discovery of signals (0 .. 60. Default value: **2 seconds**).
- **Maximum signals per meter:** Set the maximum number of signals to import for each meter (0 .. 3000. Default value: **25 signals**).
- **Description detail:** Use these options to add some extra information to the **Description** column in the **Discovered Registers** table.
 - **add tariff (disabled by default):** By enabling this option, the **Description** column will also display the tariff value.
 - **add DIF/VIF (disabled by default):** By enabling this option, the **Description** column will also display the DIF/VIF values.

Figure 16. The tariff and DIF/VIF values are added in the Description column after enabling the previous options.

Discovered Registers					Registers: 18 / 18	
Add	Reg	Description	Scale	Unit		
<input checked="" type="checkbox"/>	6	(MANUFACTURER SPECIFIC (0) (07/FFA600))	0			
<input checked="" type="checkbox"/>	7	(MANUFACTURER SPECIFIC (0) (07/FFA700))	0			
<input checked="" type="checkbox"/>	8	(MANUFACTURER SPECIFIC (0) (07/FFA800))	0			
<input type="checkbox"/>	9	(MANUFACTURER SPECIFIC (0) (07/FFA900))	0			

**NOTICE**

These options can be enabled/disabled either before or after scanning the bus.

- **Start Scan:**

- Click the **Scan** button to start scanning the M-Bus bus.

**NOTICE**

A progress bar appears, showing the scanning process.

After scanning the bus, the **Scan Results** tables will populate, showing the **Meters Newly Detected** and the **Discovered Registers** for each meter.

**NOTE**

If the **Discovered Registers** table does not show any result, click the **Readout registers** button from the **Check Meters reading** option.

- Click the **Stop** button to stop scanning the M-Bus bus.

**NOTICE**

The devices already listed will not disappear.

9.4.1.3. Scan Results

Check Meters reading Readout registers

Scan Results

Meters Newly Detected Meters: 1 / 3

Enabled	M-Bus Meter	Address	Identifier	Manufacturer ID	Version	Medium	Baudrates
<input checked="" type="checkbox"/>	Meter 0	0	00579287	Acme	32	2: Electricity	2400
<input checked="" type="checkbox"/>	Meter 1	1	12745519	Acme	32	2: Electricity	1200
<input checked="" type="checkbox"/>	Meter 2	2	00286438	Acme	32	2: Electricity	4800

Discovered Registers Registers: 18 / 18

Add	Reg	Description	Scale	Unit	Tariff	Dif
<input checked="" type="checkbox"/>	1	ENERGY	1	Wh	0	0E
<input checked="" type="checkbox"/>	2	(MANUFACT...	0		0	04
<input checked="" type="checkbox"/>	3	(MANUFACT...	0		0	04
<input checked="" type="checkbox"/>	4	(MANUFACT...	0		0	04
<input checked="" type="checkbox"/>	5	(MANUFACT...	0		0	04
<input checked="" type="checkbox"/>	6	(MANUFACT...	0		0	07
<input checked="" type="checkbox"/>	7	(MANUFACT...	0		0	07
<input checked="" type="checkbox"/>	8	(MANUFACT...	0		0	07
<input checked="" type="checkbox"/>	9	(MANUFACT...	0		0	07
<input checked="" type="checkbox"/>	10	FW VER	0		0	0D
<input checked="" type="checkbox"/>	11	(MANUFACT...	0		0	0D
<input checked="" type="checkbox"/>	12	POWER	-2	W	0	04
<input checked="" type="checkbox"/>	13	ELECTRICA...	-1	V	0	04
<input checked="" type="checkbox"/>	14	ELECTRICA...	-3	A	0	04

Update Meters baudrate


 Replace Meters / Signals
 Replace Meters
 Add Meters

Once the scanning of the M-Bus bus is completed, the discovered meters will appear in the **Meters Newly Detected** table. The registers of the selected meter appear in the **Discovered Registers** table.

CHANGING A METER'S BAUDRATE

**IMPORTANT**


Once discovered, meters with different baud rates must be configured to use the same baud rate as the gateway.



1. Use the dropdown menu from the **Baudrate** column to select the desired baudrate.
2. Click the **Update Meters baudrate** button.
3. A message will inform that the new baudrate has been accepted by the meters or, conversely, that a meter has refused the new baudrate.

UPDATE A REGISTER'S DATA

Check Meters reading: Click the **Readout registers** button to update the data of registers.



9.4.1.4. Importing Newly Discovered Meters and Registers

NOTICE Only for projects based on a Modbus BMS: An extra option named **Include Scale Conversions** appears in the lower menu (enabled by default). This functionality applies the conversion of scales for the selected registers. If so, the **Conversions** column in the **Signals** tab will show **Enabled**. To know more see [Signals Tab \(page 52\)](#).

REPLACE THE EXISTING METERS AND SIGNALS OF YOUR INTESIS MAPS PROJECT



IMPORTANT

This option will remove any existing meter and its signals from your project.

To replace your project's meters and their registers with the newly detected ones, follow this procedure:

1. In the **Meters Newly Detected** table, use the checkbox in the **Enabled** column to select the meters you want to import to your project.
2. In the **Discovered Registers** table, use the checkbox in the **Add** column to select the meter registers you want to import to your project.
3. Ensure that the **Replace Meters / Signals** option is enabled in the bottom menu.
4. Click **Save**.

REPLACE THE EXISTING METERS OF YOUR INTESIS MAPS PROJECT, BUT KEEPING THEIR SIGNALS



IMPORTANT

This option will remove any existing meter from your project, but its signals will be kept.

To replace your project's meters with the newly detected ones, but keeping their registers, follow this procedure:

1. In the **Meters Newly Detected** table, use the checkbox in the **Enabled** column to select the meters you want to import to your project.
2. In the **Discovered Registers** table, use the checkbox in the **Add** column to select the meter registers you want to import to your project.
3. Ensure that the **Replace Meters** option is enabled in the bottom menu.
4. Click **Save**.

ADD THE NEWLY DISCOVERED METERS AND THEIR SIGNALS TO YOUR MAPS PROJECT

To add the newly detected meters and their signals to your project while keeping the meters and signals you already have, follow this procedure:




NOTE

With this option, any existing meter and its signals will be kept.

1. In the **Meters Newly Detected** table, use the checkbox in the **Enabled** column to select the meters you want to import to your project.
2. In the **Discovered Registers** table, use the checkbox in the **Add** column to select the meter registers you want to import to your project.
3. Ensure that the **Add Meters** option is enabled in the bottom menu.
4. Click **Save**.

Figure 17. Newly discovered meters (Meter 0, Meter 1, and Meter 2) are added to the meters already configured in the project (Energy meter, Energy meter2, and Gas meter).




IMPORTANT

Whatever option you use to add meters to your project, remember that the total number of meters/devices supported by the gateway depends on the purchased license. To know more, consult the sections **Licensing** and **Gateway Capacity** in the IN712MEB***0000 [User Manual](#).

9.4.2. M-Bus Meters Configuration

CONFIGURE THE M-BUS BUS



Select the root of the tree view (**M-Bus Devices**) to set up the following options:

- **Baudrate:** Use the dropdown menu to select the baudrate for all the M-Bus meters in bits per second.
 - 300, 600, 1200, 2400, 4800, 9600 (Default value: **2400 bps**).



NOTICE

The most common baudrate for M-Bus networks is 2400 bps.

- **Continuous polling (enabled by default):** Enable/disable the continuous polling of the bus by the gateway.
- **Read on Start (enabled by default):** Enable/disable the reading of all values by the gateway on start.
- **Add Meter(s):** Type or select the number of meters you want to add to the project and click the **Add** button. You can also import a template from your local storage. To do so, follow this procedure:

1. Click the **Add From Template** button.
2. In the **M-BUS Server Templates** window, click **Import file**.
3. Select the desired M-Bus device template from a local folder on your computer and click **Open**.
4. The **Template Available Objects** section will populate with the signals included in the selected template.
5. If needed, filter the signals you want to import into your project:
 - a. Click any signal's checkbox in the **Active** column to deselect that signal.
 - b. Disable the **Import disabled objects** option below the table of signals.
6. Click **Apply** to import the selected signals into your project.



IMPORTANT

Whatever option you use to add meters to your project, remember that the total number of meters/devices supported by the gateway depends on the purchased license. To know more, consult the sections **Licensing** and **Gateway Capacity** in the IN712MEB***0000 [User Manual](#).

- **Status signals:** Select how to check the status of the M-Bus meters.
 - **Combine Signals (default value):** A unique 1 byte signal groups five different statuses for each meter.

43	<input checked="" type="checkbox"/>	Force reading Device 0	3: BV	0	-	Energy meter	4: Force Device reading
44	<input checked="" type="checkbox"/>	Timestamp Device 0	46: ...	1	secon...	Energy meter	8: Timestamp
45	<input checked="" type="checkbox"/>	Serial number Device 0	46: ...	2	no_u...	Energy meter	7: Meter Serial Number
46	<input checked="" type="checkbox"/>	Status M-BUS Device 0	0: AI	51	no_u...	Energy meter	5: M-BUS Status
47	<input checked="" type="checkbox"/>	Comm Error Device 1	3: BI	9	-	Energy meter2	0: Comm Error
48	<input checked="" type="checkbox"/>	Force reading Device 1	5: BV	7	-	Energy meter2	4: Force Device reading
49	<input checked="" type="checkbox"/>	Timestamp Device 1	46: ...	1	secon...	Energy meter2	8: Timestamp

- **Separate Signals:** Five specific signals show each possible status of the meter:

43	<input checked="" type="checkbox"/>	Force reading Device...	3: BV	0	-	Energy meter	4: Force Device reading
44	<input checked="" type="checkbox"/>	Timestamp Device 0	46: ...	1	secon...	Energy meter	8: Timestamp
45	<input checked="" type="checkbox"/>	Serial number Devi...	46: ...	2	no_u...	Energy meter	7: Meter Serial Number
46	<input checked="" type="checkbox"/>	Application error De...	0: AI	51	no_u...	Energy meter	5: M-BUS Status
47	<input checked="" type="checkbox"/>	Power low Device 0	3: BI	9	no_u...	Energy meter	5: M-BUS Status
48	<input checked="" type="checkbox"/>	Permanent error De...	3: BI	10	no_u...	Energy meter	5: M-BUS Status
49	<input checked="" type="checkbox"/>	Temporary error De...	3: BI	11	no_u...	Energy meter	5: M-BUS Status
50	<input checked="" type="checkbox"/>	Manufacturer error ...	0: AI	52	no_u...	Energy meter	5: M-BUS Status
51	<input checked="" type="checkbox"/>	Comm Error Device 1	3: BI	12	-	Energy meter2	0: Comm Error
52	<input checked="" type="checkbox"/>	Force reading Device...	5: BV	7	-	Energy meter2	4: Force Device reading
53	<input checked="" type="checkbox"/>	Timestamp Device 1	46: ...	1	secon...	Energy meter2	8: Timestamp

- **Meters timestamp format:** Select the format for time and date signals for all the M-Bus meters in the bus.
 - **Epoch time (selected by default):** This option reports the number of seconds that have elapsed since January 1, 1970, at 00:00:00 UTC.



NOTICE

If the meter timestamp signal reports a 0, the date it is providing is before or equal to January 1, 1970, at 00:00:00 UTC.

- **M-Bus type:** This option uses the M-Bus data type F = Compound CP32: Date and Time.
- **Show Advanced Configuration (deselected by default):** Select this option to enable the M-Bus meters advanced configuration.

**IMPORTANT**

This menu provides advanced functionalities intended for expert users.

We recommend keeping these options set to their default values.

- **Manage Timeouts:** Click the **Advanced** button to open the **Timeout Management** menu.
- **Time Interframe:** Set the time, in milliseconds, to add to the standard minimum interframe time (0 .. 30000. Default value: **0 ms**).
- **Reset Response Timeout¹** and **User Data Response Timeout²:** Set a specific timeout, in milliseconds, for both options and for each baudrate.

**NOTE**

¹ **Reset Response Timeout:** Timeout after a SND_NKE transmission.

² **User Data Response Timeout:** Timeout after a REQ_UD2 transmission

- **300 bps:** 500 .. 30000. Default value: **10500 ms**.
- **600 bps:** 500 .. 30000. Default value: **5500 ms**.
- **1200 bps:** 500 .. 30000. Default value: **3000 ms**.
- **2400 bps:** 500 .. 30000. Default value: **1500 ms**.
- **4800 bps:** 500 .. 30000. Default value: **1000 ms**.
- **9600 bps:** 500 .. 30000. Default value: **500 ms**.
- **Application Reset on start of polling (disabled by default):** Enable/disable the application reset before every polling cycle. When enabled, another option appears:
- **Application Reset Subcode for polling (disabled by default):** When enabled, adds a reset subcode to the application reset in each polling cycle. Use the dropdown menu below the option to select the desired subcode.
- **Inter-Polling Gap:** Set the time in seconds between polling cycles (1 .. 65535. Default value: **10 seconds**).

CONFIGURE THE M-BUS METERS

The screenshot shows the 'Meters Configuration' window. On the left, a tree view under 'M-Bus Devices' lists 'Energy meter', 'Energy meter2', 'Gas meter', 'Meter 0', 'Meter 1', and 'Meter 2'. 'Energy meter' is selected and highlighted with a red box. On the right, the configuration details for 'Energy meter' are shown, also enclosed in a red box. The fields include: Meter Name (Energy meter), Addressing Mode (Primary selected), Address (1), Identifier (1), Manufacturer ID (ABC), Software Version (1), Medium (1), Baudrate (2400 bps), Clone Meter (Clone button), Export Template (Export button), and Delete Meter (Delete button).

Select any meter from the tree view to set up the following options:

**NOTICE**

Greyed-out options are not editable.

- **Meter Name:** Type a name for the meter.
- **Addressing Mode:** Set the redirection mode for the meter.
 - **Primary (selected by default):** The meter uses the primary addressing mode.
 - **Address:** Type or select the meter's primary address (1 .. 250).
 - **Secondary:** The meter uses the secondary addressing mode.
 - **Identifier:** Type the secondary address identifier for this meter (0 .. 99999999).
 - **Manufacturer ID:** Type the meter's manufacturer ID. Three characters maximum.

**NOTICE**

By selecting the **Disable** option, this parameter will not be used to identify the meter.

- **Software Version:** Type or select the meter's software version (0 .. 255).

**NOTICE**

By selecting the **Disable** option, this parameter will not be used to identify the meter.

- **Medium:** Type or select the meter's medium (0 .. 255).

**NOTICE**

By selecting the **Disable** option, this parameter will not be used to identify the meter.

- **Baudrate (not editable):** This option shows the baudrate of this meter. This value can be edited from the root of the tree view (**M-Bus Devices**) as explained before.

**NOTICE**

Edit this option from the root of the tree view for manually added meters, as explained before in this section, and from the scan menu for meters imported using the scan function, as explained in [Scan Results \(page 44\)](#).

- **Clone Meter:** When cloning a meter, one or more new meters with the same configuration and signals are created.

**IMPORTANT**

The total number of meters/devices supported by the gateway depends on the purchased license. To know more, consult the sections **Licensing** and **Gateway Capacity** in the [IN712MEB***0000 User Manual](#).

1. Click **Clone**.
 2. Type or select the number of **Devices to Add**.
 3. Click **Apply**.
- **Export Template:** Save a template with the meter's configuration.
 1. Click **Export**.
 2. Type a **File name**.


3. Select a folder to save the file.
4. Click **Save**.

- **Delete Meter:** Click the **Delete** button to delete the meter.

To avoid losing data by mistake, after deleting a meter, its associated registers remain visible in the **Signals** tab, but their text will appear dimmed, and the **Device** column shows **---**.

28	<input checked="" type="checkbox"/>	Device 1 Volume	10	0: Unsigned	05	- 0: Read	Meter 1	0: Measure	2 -
29	<input checked="" type="checkbox"/>	Device 1 Temperature	16	0: Unsigned	64	- 0: Read	Meter 2	6: Measure	3 -
30	<input checked="" type="checkbox"/>	Device 2 Energy	64	0: Unsigned	65	- 0: Read	-	6: Measure	1 -
31	<input checked="" type="checkbox"/>	Device 2 Volume	16	0: Unsigned	69	- 0: Read	-	6: Measure	2 -
32	<input checked="" type="checkbox"/>	Device 2 Temperature	16	0: Unsigned	70	- 0: Read	-	6: Measure	3 -

Given this situation, an error message will appear when checking the signals table:



To solve this problem, select all the registers of the deleted meter and click the **-** button to definitely remove them from the table.

29	<input checked="" type="checkbox"/>	Device 1 Temperature	10	0: Unsigned	04	- 0: Read	Meter 1	0: Measure	2 -
30	<input checked="" type="checkbox"/>	Device 2 Energy	64	0: Unsigned	65	- 0: Read	-	6: Measure	1 -
31	<input checked="" type="checkbox"/>	Device 2 Volume	16	0: Unsigned	69	- 0: Read	-	6: Measure	2 -
32	<input checked="" type="checkbox"/>	Device 2 Temperature	16	0: Unsigned	70	- 0: Read	-	6: Measure	3 -

Active signals: 29 / 3000 Hide Disabled signals Edit Columns Import Export AA ↑ ↓ +(N) 3 - Check table



TIP

Instead of deleting them, you can add these registers to another active meter.

10. Signals Tab

The **Signals** menu shows a table used to define and configure the signals needed for the project.

After three columns displaying the number of the signal (**#**), a checkbox to select if the signal is **Active** or not in the project, and an editable cell for the signal's **Description**, several columns with a dark grey header appear, showing the protocols of your current project:



NOTICE

Use the horizontal and vertical scroll bars to view all the rows and columns.

Figure 18. Signals tab for a BACnet BMS.

#	Active	Description	BACnet Server			M-Bus					
			Name	Type	Units	Device	M-Bus Code	Register	Magnitude	Units	Conversions
7	<input checked="" type="checkbox"/>	Force reading Device...	5: BV	2	-	Meter 1	4: Force Device reading	-	-	-	-
8	<input checked="" type="checkbox"/>	Timestamp Device 0	46: LAV	1	seconds (73)	Meter 1	8: Timestamp	-	-	-	-
9	<input checked="" type="checkbox"/>	Serial number Device...	46: LAV	2	no_units (95)	Meter 1	7: Meter Serial Number	-	-	-	-
10	<input checked="" type="checkbox"/>	Application error D...	0: AI	12	no_units (95)	Meter 1	5: M-BUS Status	-	-	-	-
11	<input checked="" type="checkbox"/>	Power low Device 0	3: BI	5	-	Meter 1	5: M-BUS Status	-	-	-	-
12	<input checked="" type="checkbox"/>	Permanent error De...	3: BI	6	-	Meter 1	5: M-BUS Status	-	-	-	-
13	<input checked="" type="checkbox"/>	Temporary error De...	3: BI	7	-	Meter 1	5: M-BUS Status	-	-	-	-
14	<input checked="" type="checkbox"/>	Manufacturer error ...	0: AI	13	no_units (95)	Meter 1	5: M-BUS Status	-	-	-	-
15	<input checked="" type="checkbox"/>	Comm Error Device 1	3: BI	3	-	Meter 2	0: Comm Error	-	-	-	-
16	<input checked="" type="checkbox"/>	Force reading Devic...	5: BV	3	-	Meter 2	4: Force Device reading	-	-	-	-
17	<input checked="" type="checkbox"/>	Timestamp Device 1	46: LAV	3	seconds (73)	Meter 2	8: Timestamp	-	-	-	-
18	<input checked="" type="checkbox"/>	Serial number Devic...	46: LAV	4	no_units (95)	Meter 2	7: Meter Serial Number	-	-	-	-
19	<input checked="" type="checkbox"/>	Application error D...	0: AI	14	no_units (95)	Meter 2	5: M-BUS Status	-	-	-	-
20	<input checked="" type="checkbox"/>	Power low Device 1	3: BI	8	-	Meter 2	5: M-BUS Status	-	-	-	-
21	<input checked="" type="checkbox"/>	Permanent error De...	3: BI	9	-	Meter 2	5: M-BUS Status	-	-	-	-
22	<input checked="" type="checkbox"/>	Temporary error De...	3: BI	10	-	Meter 2	5: M-BUS Status	-	-	-	-
23	<input checked="" type="checkbox"/>	Manufacturer error ...	0: AI	15	no_units (95)	Meter 2	5: M-BUS Status	-	-	-	-
24	<input checked="" type="checkbox"/>	Comm Error Device 2	3: BI	4	-	Meter 3	0: Comm Error	-	-	-	-
25	<input checked="" type="checkbox"/>	Force reading Devic...	5: BV	4	-	Meter 3	4: Force Device reading	-	-	-	-
26	<input checked="" type="checkbox"/>	Timestamp Device 2	46: LAV	5	seconds (73)	Meter 3	8: Timestamp	-	-	-	-
27	<input checked="" type="checkbox"/>	Serial number Devic...	46: LAV	6	no_units (95)	Meter 3	7: Meter Serial Number	-	-	-	-
28	<input checked="" type="checkbox"/>	Application error D...	0: AI	16	no_units (95)	Meter 3	5: M-BUS Status	-	-	-	-
29	<input checked="" type="checkbox"/>	Power low Device 2	3: BI	11	-	Meter 3	5: M-BUS Status	-	-	-	-
30	<input checked="" type="checkbox"/>	Permanent error De...	3: BI	12	-	Meter 3	5: M-BUS Status	-	-	-	-
31	<input checked="" type="checkbox"/>	Temporary error De...	3: BI	13	-	Meter 3	5: M-BUS Status	-	-	-	-
32	<input checked="" type="checkbox"/>	Manufacturer error ...	0: AI	17	no_units (95)	Meter 3	5: M-BUS Status	-	-	-	-
33	<input checked="" type="checkbox"/>	Device0_Reg0	0: AI	3	no_units (95)	Meter 1	6: Measure	1	-	-	-
34	<input checked="" type="checkbox"/>	Device0_Reg1	0: AI	4	no_units (95)	Meter 1	6: Measure	2	-	-	-
35	<input checked="" type="checkbox"/>	Device0_Reg2	0: AI	5	no_units (95)	Meter 1	6: Measure	3	-	-	-
36	<input checked="" type="checkbox"/>	Device1_Reg0	0: AI	6	no_units (95)	Meter 2	6: Measure	1	-	-	-
37	<input checked="" type="checkbox"/>	Device1_Reg1	0: AI	7	no_units (95)	Meter 2	6: Measure	2	-	-	-
38	<input checked="" type="checkbox"/>	Device1_Reg2	0: AI	8	no_units (95)	Meter 2	6: Measure	3	-	-	-
39	<input checked="" type="checkbox"/>	Device2_Reg0	0: AI	9	no_units (95)	Meter 3	6: Measure	1	-	-	-

Auto BACName: Auto BACInst. Active signals: 41 / 3000

Hide Disabled signals Edit Columns Import Export A/A ↑ ↓ + (0) 3 Check table

1. Protocol of the control system:
 - Modbus Slave
 - BACnet Server
2. Protocol of the server network:
 - M-Bus

On the bottom menu placed below the table of signals, these options are available:

- **Auto BACName:** Check this option to automatically add the BACnet type and BACnet instance as a prefix to the current name field.



NOTE

This parameter is only available for **BACnet**.

- **Auto BACInst.:** Generates all BACnet instance numbers automatically, avoiding the risk of duplicate values.



NOTE

This parameter is only available for **BACnet**.

- **Active signals:** Number of active signals / total number of signals.
- **Hide Disabled signals (disabled by default):** Show/hide all disabled signals from the list.
- **Edit Columns:** Click this button to hide/show any column of the table.
- **Export:** Click this button to export the current signals' configuration to an XLSX file for later import, helping to reduce commissioning time.



TIP

The **Import** and **Export** options can help you reduce commissioning time. However, you can also export and import the whole project's configuration, including the signal's settings, as explained in [Saving, Opening, Importing, and Exporting the Project \(page 10\)](#).

- **A:** Increases or decreases the font size.
- Click the **Check table** button to review the signals' configuration.



NOTE

If any parameter on any signal is wrong, a message will emerge with specific information about the error.

10.1. Adding and Deleting Signals

ADDING SIGNALS



TIP

New signals are added below the row you have currently selected.

1. Select any cell from the desired row.
For example, given this case, the new signal will be added below row 35:

32	<input checked="" type="checkbox"/>	Manufacturer error ...	0: AI	5 no_u...	Meter 3	5: M-BUS Status	-	-	-
33	<input checked="" type="checkbox"/>	Device 0 Energy	46: LAV	7 no_u...	Meter 1	6: Measure	1	-	-
34	<input checked="" type="checkbox"/>	Device 0 Volume	0: AI	6 no_u...	Meter 1	6: Measure	2	-	-
35	<input checked="" type="checkbox"/>	Device 0 Temperature	0: AI	7 no_u...	Meter 1	6: Measure	3	-	-
36	<input checked="" type="checkbox"/>	Device 1 Energy	46: LAV	8 no_u...	Meter 2	6: Measure	1	-	-
37	<input checked="" type="checkbox"/>	Device 1 Volume	0: AI	8 no_u...	Meter 2	6: Measure	2	-	-
38	<input checked="" type="checkbox"/>	Device 1 Temperature	0: AI	9 no_u...	Meter 2	6: Measure	3	-	-
39	<input checked="" type="checkbox"/>	Device 2 Energy	46: LAV	9 no_u...	Meter 3	6: Measure	1	-	-

2. Use the option from the bottom menu to type or select the number of rows to add.



NOTE

Add one row for each signal you want to add.

- Click the **+ (N)** button from the bottom menu to add the needed rows.

For example, after adding three rows, these appear numbered 36, 37, 38:

32	<input checked="" type="checkbox"/>	Manufacturer error ...	0: AI	5 no_u...	Meter 3	0: M-BUS Status	-	-
33	<input checked="" type="checkbox"/>	Device 0 Energy	46: LAV	7 no_u...	Meter 1	6: Measure	1	-
34	<input checked="" type="checkbox"/>	Device 0 Volume	0: AI	6 no_u...	Meter 1	6: Measure	2	-
35	<input checked="" type="checkbox"/>	Device 0 Temperature	0: AI	7 no_u...	Meter 1	6: Measure	3	-
36	<input type="checkbox"/>	New Object_56	0: AI	16 no_u...	-	6: Measure	1	-
37	<input type="checkbox"/>	New Object_57	0: AI	17 no_u...	-	6: Measure	1	-
38	<input type="checkbox"/>	New Object_58	0: AI	18 no_u...	-	6: Measure	1	-

As shown in the image before, once added, new signals appear with dimmed text. Once you assign a device to the new signal, the text turns black.

For example, we are adding the signal 36 named **New Object_56** to the M-Bus **Meter 1**:

35	<input checked="" type="checkbox"/>	Device 0 Energy	46: LAV	7 no_u...	Meter 1	6: Measure	-	-
34	<input checked="" type="checkbox"/>	Device 0 Volume	0: AI	6 no_u...	Meter 1	6: Measure	-	-
35	<input checked="" type="checkbox"/>	Device 0 Temperature	0: AI	7 no_u...	Meter 1	6: Measure	-	-
36	<input type="checkbox"/>	New Object_56	0: AI	16 no_u...	-	6: Measure	-	-
37	<input type="checkbox"/>	New Object_57	0: AI	17 no_u...	-	6: Measure	-	-
38	<input type="checkbox"/>	New Object_58	0: AI	18 no_u...	-	6: Measure	-	-
39	<input checked="" type="checkbox"/>	Device 1 Energy	46: LAV	8 no_u...	Meter 2	6: Measure	-	-
40	<input checked="" type="checkbox"/>	Device 1 Volume	0: AI	8 no_u...	Meter 2	6: Measure	-	-
41	<input checked="" type="checkbox"/>	Device 1 Temperature	0: AI	9 no_u...	Meter 2	6: Measure	-	-
42	<input checked="" type="checkbox"/>	Device 2 Energy	46: LAV	9 no_u...	Meter 3	6: Measure	-	-



TIP

You can assign multiple signals to the same device using a multiple selection. To know more, see [Editing Signals \(page 55\)](#).

Don't forget to select the new signal's checkbox in the **Active** column to include the signal in your project:

33	<input checked="" type="checkbox"/>	Device 0 Energy	46: LAV	7 no_u...	Meter 1	6: Measure	-	-
34	<input checked="" type="checkbox"/>	Device 0 Volume	0: AI	6 no_u...	Meter 1	6: Measure	-	-
35	<input checked="" type="checkbox"/>	Device 0 Temperature	0: AI	7 no_u...	Meter 1	6: Measure	-	-
36	<input checked="" type="checkbox"/>	New Object_56	0: AI	16 no_u...	Meter 1	6: Measure	-	-
37	<input type="checkbox"/>	New Object_57	0: AI	17 no_u...	-	6: Measure	-	-
38	<input type="checkbox"/>	New Object_58	0: AI	18 no_u...	-	6: Measure	-	-
39	<input checked="" type="checkbox"/>	Device 1 Energy	46: LAV	8 no_u...	Meter 2	6: Measure	-	-
40	<input checked="" type="checkbox"/>	Device 1 Volume	0: AI	8 no_u...	Meter 2	6: Measure	-	-

DELETING SIGNALS

- Select any cell from the signal you want to delete.
- Click the **-** button from the bottom menu.



IMPORTANT

This action cannot be undone.



TIP

You can delete multiple signals using a multiple selection. To know more, see [Editing Signals \(page 55\)](#).

10.2. Editing Signals

All templates include a column called **Description**, whose cells are editable fields.



TIP

Use the **Description** column to type a text that makes the signal easily recognizable.

MULTIPLE SELECTION

- **Selecting multiple contiguous cells:**

1. Click the first cell of your selection to select it.
2. Press and hold the shift key on your keyboard.
3. Click the last cell of your selection.



TIP

You can click a cell and drag the cursor over the other cells instead.

- **Selecting multiple non-contiguous cells:**

1. Click the first cell of your selection to select it.
2. Press and hold the Ctrl key on your keyboard.
3. Click the rest of the cells of your selection one by one.

EDITING MULTIPLE PARAMETERS


Once you have multiple parameters selected, you can edit them simultaneously:

For example, we are adding signals 37 to 44 to the M-Bus **Meter 1**:

36	<input checked="" type="checkbox"/>	New Object_56	0: AI	16	no_u...	Meter 1	6	Measure
37	<input type="checkbox"/>	New Object_57	0: AI	17	no_u...	-	6	Measure
38	<input type="checkbox"/>	New Object_58	0: AI	18	no_u...	-	6	Measure
39	<input type="checkbox"/>	New Object_62	0: AI	22	no_u...	-	6	Measure
40	<input type="checkbox"/>	New Object_63	0: AI	23	no_u...	-	6	Measure
41	<input type="checkbox"/>	New Object_64	0: AI	24	no_u...	-	6	Measure
42	<input type="checkbox"/>	New Object_59	0: AI	19	no_u...	-	6	Measure
43	<input type="checkbox"/>	New Object_60	0: AI	20	no_u...	-	6	Measure
44	<input type="checkbox"/>	New Object_61	0: AI	21	no_u...	-	6	Measure
45	<input checked="" type="checkbox"/>	Device 1 Energy	46: LAV	8	no_u...	Meter 1	6	Measure
48	<input checked="" type="checkbox"/>	Device 2 Energy	46: LAV	9	no_u...	Meter 2	6	Measure
34	<input checked="" type="checkbox"/>	Device 0 Volume	0: AI	6	no_u...	Meter 3	6	Measure
46	<input checked="" type="checkbox"/>	Device 1 Volume	0: AI	8	no_u...	Meter 2	6	Measure

Together with the multiple selection, you can use the **Auto Enumeration Parameters** functionality for some parameters.

For example, we are setting the address for these Modbus registers, starting from address 0 and incrementing the subsequent registers by 1 through this functionality:




11. Receive/Send Tab

Send:

Once you have finished setting the parameters, you have to send the configuration to the gateway:

1. Click the **Send** button.
 - a. If the gateway is still factory-set, you will be prompted to save the project on your PC. Once saved, the configuration is automatically sent to the gateway.
 - b. If you have already saved the project, the configuration is automatically sent to the gateway.
2. Connect again with the gateway after sending the file.



NOTICE

The gateway reboots automatically once the new configuration is loaded. This process may take a few seconds.

Receive:

Use this function to load the configuration of a gateway to Intesis MAPS.



TIP

This function may be helpful when you need to change some parameters of an already configured gateway.

Once the configuration is completed and sent, the gateway is already operative. Even so, you should review that everything works correctly by entering the **Diagnostic** tab.


12. Diagnostic Tab




IMPORTANT

Connection with the gateway is required to use the diagnostic tools.

Figure 19. Diagnostic tab window. Find the ToolBox between the upper tabs bar and the Console view. Below it, from left to right: Console viewer, Protocol viewers (one above the other), and the Signals viewer



TOOLBOX



From left to right:

- **Microprocessor icon:** Check the current hardware status of the gateway.
- **LOG:** Set Intesis MAPS in logging mode to record all the information present in the viewers and save it in a .zip file.
- **INFO?:** Get some gateway information.
- **RESET:** Reset the gateway.

**NOTE**

Depending on your screen resolution, the **ToolBox** icons may appear partially hidden behind the **Viewers** window.

VIEWERS

Intesis MAPS provides several viewers:


- A generic console viewer for general information about communications and the gateway status.
- A viewer for both protocols to check their current status.
- A signals viewers to simulate the BMS behavior or check the system's current values.

**NOTE**

Use the refresh button to get updated values on the signals viewer.

The layout of these viewers can be modified:

- Using the **Select Diagnostics View** option from the **View** menu:

**NOTE**

Layouts 3 and 4 offer two different tabbed options:


- Fixed console to the left and tabbed browser for the other viewers
- Full tabbed browser

- Clicking and dragging the border of a viewer. To do so, place the cursor over the edge of a viewer. On the vertical edges, the cursor changes to  to adjust the width, and on the horizontal edges, the cursor changes to  to adjust the height.

Viewers can also be arranged manually by clicking and dragging them from their title bar, to use them as independent windows or to position them in relation to other viewers.

FILTERING

A filtering tool is available for the console and the bus viewers to find the desired information more efficiently. To use this tool, right-click on the viewer.



The options available for this tool are:

- **Copy selected to clipboard:** It copies the selected text into the clipboard. If no text is selected, this option is disabled.
- **Copy all to clipboard:** It copies all the information from the viewer to the clipboard.
- **Enable filter:** This option enables or disables the configured filter. To use this option, a filter must be defined beforehand under Filter configuration.

- **Filter configuration:** The filter itself is defined here, using some additional options:

- **Search Condition:**

- **Filter Type:**

- **Plain text:** It searches all the communication frames that include the text specified in the **Search Condition String** below.
 - **Regular Expression:** It searches all the communication frames that match the regular expression specified in the **Search Condition String** below.



NOTE

A regular expression is a sequence of characters that specifies a match pattern in text. If you are not familiar with regular expressions, use the **Plain text** option instead.

- **Display:**

- **Visualization Options:**

- **Filter:** It removes all the communication frames that do not fulfill the filter condition specified in the **Search Condition String**.
 - **Highlight:** It highlights the communication frames that fulfill the filter condition specified in the **Search Condition String**.

13. Late Configuration: Change the Gateway's Protocol

Reconfiguring the gateway with a different protocol is very easy:

1. Connect the gateway to the PC and open the configuration tool Intesis MAPS.
2. Select the new template you need.
3. Click **Next** or double-click the template in the list.
4. Enter the **Connection** tab, select the gateway, and click the **Connect** button.
5. A dialog will ask if you want to save the project that is currently loaded in the gateway.
6. Click **Yes** or **No**, depending on your needs.
7. A new dialog appears showing the **Gateway Current Status** and the **Firmware Update Information**.
8. Click **Send** to load the new firmware into the gateway.
9. In the confirmation dialog, click **Yes**.
10. Once the firmware transfer is completed, click the **Connect** button to connect with the gateway again.
11. Configure the project as usual.